



Fitting Instructions

DETACHABLE TOWBAR **G92Q**
For VAUXHALL ASTRA
2004 –

MATERIALS

A	1	Cross Bar
ZQ	1	ZQ2030 Detachable Kit
D	1	LH Spreader Plate
E	1	RH Spreader Plate
F	2	Bushes 19mm O.D, 60 Long
G	4	Bushes 19mm O.D, 56 Long
H	6	M10 x 100 x 1.5 Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D)
ZEP2	1	Electrical Plate with M12 x 25mm Flat Washer.

FITTING

1. Remove rear panel along boot edge, remove boot floor covering, loosen boot side trims and pull to centre to reveal dimples in boot floor.
2. Drill out dimples to sufficient diameter to insert bushes (F and G).
3. Insert bushes (F and G) into chassis. Attach spreader plates (D and E) using bolts (H). **Note:** Ensure good mating surface between spreader plates and boot floor, (any acoustic sound proofing agent must be removed).
4. Lower rearmost exhaust box (2 rubbers) and loosely attach crossbar (A) to Bolts (H) using nuts and washers (H) taking care not to damage bumper with centre of Cross Bar (A).
5. **Tighten all Bolts** and Refit exhaust hangers (Note: it may be necessary to bend the exhaust hangers down slightly on Sport Models to give sufficient clearance from Cross Bar (A)).
6. **Please refer to ZQ fitting instruction for fitment of Part ZQ.**

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: Grade 8.8 M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm
Grade 10.9 M12 – 139Nm

