



Fitting Instructions

TOWBAR HN36
For HONDA ACCORD COUPE (CD7)
1994- Jan 1998

MATERIALS

A	1	Main Cross Bar
A1	1	Forward Cross Bar
C	1	Centre Tube with international facing to ISO 3853 (BS AU114)
D	2	M12 x 50mm Bolts, Nuts, Lock Washers and large Flat Washers (50mm O.D.)
E	6	M12 x 30mm Bolts, Nuts and Lock Washers
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers

FITTING

1. Remove the bumper (pull out 5 plastic fixings on top and 2 underneath, 2 screws at each tip - pull out tips and slide rearwards).
2. Remove and discard the frame blanking plates and attach Cross Bar (A) with Bolts (D) and (E).
NOTE: Fit large washers in the depressions at top Bolts (D) - scrape off any mastic compound to ensure correct seating of cross bar. Put 2 Bolts (E) in centre of cross bar and refit bumper.
3. Loosely attach Forward Cross Bar (A1) to the 2 long chassis bolts.
4. Attach Centre Tube (C) to both cross bars with Bolts (E) and finally tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

