



Fitting Instructions

TOWBAR HY13A
For HYUNDAI H100
1993 - 2001

MATERIALS

A	1	Tubular Cross Bar with international facing to ISO 3853 (BS AU114)
B	1	10mm Coupling spacer
C	2	Side Arms (1 off each hand)
D	8	M12 X 30mm X 1.25mm fine pitch Bolts, Lock Washers and Flat Washers (30mm O.D.)
G	4	M12 X 35mm X 1.75mm pitch Bolts and Nyloc Nuts
H	1	Fog light mounting bracket
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Loosely attach the Side Arms (C) to the holes provided in the frame with the fine pitch Bolts (D). (It is essential to ensure that threaded holes and seating area on vehicle are cleared of underseal).
2. Attach Cross Bar (A) to the side arms with Bolts (G) and Nyloc Nuts and final tighten all bolts.

NOTE: On all models it will be necessary to discard the original fog light bracket and replace it with part (H) using existing bolts (X) and (Y).

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

