



# Fitting Instructions

TOWBAR HY26  
For HYUNDAI TRAJET  
(May 2000 -)

## MATERIALS

A	1	Tubular Crossbar with European facing to 94/20/EC – A50-1
C	4	M10x35x1.25mm Fine Pitch Bolts, Lock Washers and Washers (25mm O.D)
D	2	M10x35x1.25mm Fine Pitch Bolts, Lock Washers and Large Flat Washers (30mm O.D)
E	2	Spacers (3mm thick, use as required)
F	2	Exhaust Mounting Rubbers (Use as required)
CB	2	M16x50x2.0mm Coupling Bolts, Nuts and Lock Washers

## FITTING

1. No need to remove or cut bumper. Remove the 3 screws retaining lashing eye to left chassis rail. Release exhaust from two rearmost hangers and lower the spare wheel.
2. Remove the two **innermost** screws holding the bumper beam to chassis using 12mm socket (one on each side, located near Bolts (C)).
3. Offer up Crossbar (A) and secure using Bolts (D). Insert one or both (1 each side) of Spacers (E) if or as required between the vertical face of the vehicle frame and Tubular Crossbar (A) and attach using Bolts (C).  
**Tighten all Bolts.**
4. Reattach the two rubber exhaust hangers. **Note:** It may be necessary to replace the rearmost rubber exhaust hanging rubbers with the Exhaust Mounting Rubbers (F) provided to gain the necessary exhaust clearances on some models.

**Note:** This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

