



Fitting Instructions

TOWBAR MZ26
For MAZDA MX5
FROM 1990 – April 1998

MATERIALS

- | | | |
|----|---|---|
| A | 1 | Tubular Main Frame with international facing to ISO 3853 (BS AU114) |
| C | 2 | Side Mounting Cleats (1 off each hand) |
| D | 4 | M10 X 30mm Bolts, Nuts and Lock Washers |
| CB | 2 | M16 x 50mm Coupling Bolts, Nuts, Lock Washers |

FITTING

1. Each side remove the towing loops and loosely attach the Side Mountings (C). (Replace the top nut on the bumper mounting).
2. Attach Main Frame (A) with Bolts (D).
3. Finally tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.
Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

