



Fitting Instructions

TOWBAR RN43
For RENAULT 21 (SAVANNA) ESTATE
NOVEMBER 1986-1996
(NOT 4WD)

MATERIALS

A	1	Tubular Cross Bar with international standard facing to ISO 3853 (BS AU114)
C	2	Shaped Side Arms (1 of each hand)
D	4	M10 x 90mm bolts, Nuts, Lock Washers and Large Flat Washers (40mm O.D.)
D1	4	Bushes (54mm long – 20mm O.D.)
E	2	M10 x 30mm Bolts and Lock Washers
E1	2	Special Fixed Nuts
F	4	M12 x 30mm Bolts, Nuts and Lock Washers
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Remove the towing eye (1990 onwards). Holes are provided in the frame. At the rear holes position the Fixed Nuts (E1) inside the frame through the adjacent rectangular hole. Try a Bolt (E) first to ensure they are in the correct position before attaching the side arms.
2. When attaching the side arms, position Bushes (D1) inside the frame first with the large flat washers on the outside of the frame. Loosely attach the side arms.
3. Attach the Cross Tube (A) with Bolts (F) (about 1" of coupling height variation is provided by reversing the cross bar end for end. NOTE: 1990 onwards: To fit in the higher position it is necessary to cut a slot in the lower edge of the bumper to allow the centre tube to emerge).
4. Finally tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

