



Fitting Instructions

TOWBAR RN47
For RENAULT 21 HATCHBACK
FROM SEPTEMBER 1989- 1994
(NOT 4WD QUADRA)

MATERIALS

A	1	Towbar Mainframe with international standard facing to ISO 3853 (BS AU114)
C	2	Side Mounting Cleats (1 off each hand)
C1	2	Shaped Side Arms
D	4	M8 x 30mm Bolts, Lock Washers and Flat Washers (20mm O.D.)
D1	2	Special Brackets with M8 fixed nuts
E	4	M12 x 35mm Bolts, Nuts and Lock Washers
F	2	M10 x 100mm Bolts, Nuts, Lock Washers and large Flat Washers (40mm O.D.)
F1	2	Bushes (75mm long – 32mm O.D.)
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. No need to remove the bumper. Each side loosely attach Cleats (C) to the holes provided in the frame with Bolts (D) using the special fixings (D1). (Bend back the lip of the flange if necessary to clear the cleats).
2. Loosely attach Cross Bar (A) to the side mounts with Bolts (E) and at the same time attach Side Arms (C1) on the same bolts.
3. At the forward fixings in the frame attach with Bolts (F) using spacer Bushes (F1) and large flat washers on the outside of the frame.
4. Finally tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

