



Fitting Instructions

TOWBAR RN51
For RENAULT SAFRANE
from February 1993 - 1996

MATERIALS

| | | | |
|----|---|---|-------------------|
| A | 1 | Main Cross Bar A11 | Forward Cross Bar |
| C | 1 | Centre Tube with international facing to ISO 3853 (BS AU114) | |
| D | 3 | M10 x 30mm Bolts, Nuts, Lock Washers and large Flat Washers (40mm O.D.) | |
| E | 3 | M10 x 30mm Bolts, Nuts, Lock Washers and 2 large Flat Washers (50mm O.D.) | |
| F | 2 | M12 x 30mm Bolts, Nuts, Lock Washers and 1 large Flat Washer (40mm O.D.) | |
| CB | 2 | M16 x 50mm Coupling Bolts, Nuts and Lock Washers | |
| | 2 | M10 Bolt Caps for (E) | |

FITTING

1. Remove the bumper: 4 tip screws each side, 2 vertical and 2 horizontal small screws under the rear. Remove the rear plastic trim on the back panel and undo 4 nuts across the back. Now withdraw the bumper.
2. Attach Cross Bar (A) to the 3 holes provided in the frame with Bolts (D) - using large washers under the bolt heads. Drill through the spare wheel pan for Bolt (F).
3. Attach the Centre Tube (C) to the cross bar with Bolts (F) (large flat washer under the bolt head inside the pan on the right). Attach Forward Cross Bar (A1) to the centre tube with a Bolt (E). Offer up the assembly and square across the forward cross bar, ensuring that the outer holes come in the centre of the rib pressings.
4. Drill up for Bolts (E) and attach with 50mm large washers under the bolt heads inside. Finally tighten all bolts and replace the bumper.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

