



Fitting Instructions

TOWBAR RN62
For RENAULT MASTER VAN
(March 1998-)

MATERIALS

A	1	Towbar Main Frame
B	1	10mm Coupling Packer
D	1	Side arm
E	6	M10 x 40 x 1.5 Bolts, Lock Washers and 25mm O.D. Flat Washers
F	4	M12 x 40 x 1.75 Bolts, 2 Nuts, Lock Washers and 25mm O.D. Flat Washers
CB	2	M16 x 65mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Remove and discard bumper support arms (3 off). Remove the 2 inner most bolts securing the towing eye to the vehicle chassis.
2. Loosely attach Towbar Main Frame (A) at existing chassis mountings using Bolts (E) with Flat Washers and bumper mountings (Y) using original bolts. Attach Side arm (D) to Main Frame (A) and to captive threads in vehicle chassis using Bolts (F) with Flat Washers.
3. Finally, **Tighten all Bolts.**

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed.**

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

