



Fitting Instructions

TOWBAR RN64
For RENAULT MASTER CHASSIS CAB
(March 1998-)

MATERIALS

A	1	Towbar Main Frame with international facing to ISO 3853 (BS AU114)
B	1	10mm Coupling Packer
D	1	Side arm
E	6	M10x45x1.5 Bolts, Lock Washers and 25mm O.D. Flat Washers
F	4	M12 x 40 x 1.75 Bolts, 2 Nuts, Lock Washers and 25mm O.D. Flat Washers
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Remove and discard the 2 inner most bolts securing the left hand towing eye (where fitted).
2. Loosely attach Towbar Main Frame (A) at existing chassis mountings (E).
3. Attach Sidearm (D) to Main Frame (A) and to captive threads in vehicle chassis using Bolts (F) with Flat Washers.
4. Finally, **Tighten all Bolts.**

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.
Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

