



Fitting Instructions

TOWBAR RN72Q
for Renault Scenic 2003 –
for Renault Grande Scenic 2004 –

MATERIALS

| | | |
|------|---|---|
| A | 1 | Towbar Mainframe |
| C | 1 | Right Sidearm |
| D | 1 | Left Sidearm |
| E | 2 | M12 x 35 x 1.75 Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D) |
| F | 2 | M12 x 40 x 1.75 Bolts, Lock Washers and Large Flat Washers (40mm O.D) |
| G | 2 | M10 x 35 x 1.5 Bolts, Lock Washers and Large Flat Washers (40mm O.D) |
| H | 1 | M10 x 25 x 1.5mm Bolt, Nut, Lock Washer and 2 Flat Washers (20mm O.D) |
| ZEP1 | 1 | Electrical Plate |
| ZEQ2 | 1 | Electrical Plate Angle |
| ZQ | 1 | Detachable Swan Neck (ZQ3000) |

FITTING

1. Remove and disconnect rear light clusters (remove two visible torq screws and gently pull clusters rearward).
2. Remove bumper (4 torq screws along top edge of bumper, 2 self tapping screws on rear side of each wheel arch, 5 or 6 screws on underside of bumper, 2 plastic screws in light cluster area, both plastic door shut guides), gently pull bumper tips outwards and upwards before gently pulling bumper rearward.
3. For the **Grande Scenic only**, ensure the most rearward seats are locked in their downward most position and remove the 3 piece plastic covers located on the boot floor. (3 finger locks on the central cover and 4 screws on each of the left and right plastic covers).
4. Remove bumper reinforcement beam (hand to customer) and rubber chassis rail blanking plates, and for the **Scenic only**, the spare wheel and jack/polystyrene assembly.
5. If necessary bend/remove the metal flap blocking access to the chassis rails and insert Sidearms (C and D) into chassis rails as shown, loosely attach using Bolts (G). **Note:** Holes in chassis rails for Bolts (F and G) are covered with tape and situated behind the layer of foam.
6. Loosely attach Towbar Mainframe (A) to Sidearms (C and D) using Bolts (E and F). **For the Scenic only Note:** On left side, access for socket/extension bar for Bolts (F) is obtained by lifting up trim in boot (remove 4 torq screws hidden under plastic caps), moving foam insulation and removing blanking plug on outer skin of rear wing. **For the Grande Scenic Only:** On the left hand side access for socket/extension bar for Bolt (F) is obtained by removing the air vent and blanking plug on the outer skin. **Tighten All Bolts.**
7. Seal ends of chassis rails with tape and / or replacing rubber chassis rail blanking plates (after cutting relevant slots for Sidearms (C and D), sealant or expanding foam to prevent ingress of water. Reattach bumper.
8. Attach ZQ (Detachable Swan Neck (ZQ3000)) and Electrical Plate Angle (ZEQ2) on either side as per separate instruction. Attach Electrical Plate (ZEP1) using Bolts (H). Note: Electrical Plate may be angled up behind the bumper as shown.
9. Replace all trim, plastic covers, bumper, reversing sensor connection, spare wheel, jack/polystyrene assembly, and rear light clusters in reverse order to above.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

