



Fitting Instructions

TOWBAR SK10
For SKODA OCTAVIA
ESTATE 4WD/AGRIPPA
1999 -

MATERIALS

A	1	Cross Tube
C	1	Centre Tube with European facing to 94/20/EC A50-1
D	1	Left Hand Sidearm
E	1	Right Hand Sidearm
F	4	M10 x 30mm Bolts, Lock Washers and Large Flat Washers (30mm O.D.)
G	4	M12 x 30mm Bolts, Nuts, Lock Washers and Flat Washers (25mm O.D.)
H	2	M12 x 75mm Bolts and Nyloc Nuts
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers

FITTING

1. Remove bumper - 2 bolts and 1 nut behind rear trim side panels, remove mud flaps and tip screws, remove torx head screws around lower edge of bumper.
2. Remove bumper cross beam from vehicle and discard (or retain for fitment when bracket is removed). Position Sidearms (D) and (E) inside chassis and very loosely secure using Bolts (F) at existing holes (covered in tape) with Large Flat Washers. Secure Cross Tube (A) to Sidearms using Bolts (G) with Flat Washers. Tighten all bolts.
3. Cut two 10mm wide x 40mm long slots in bumper as shown below and refit bumper.
4. Attach Centre Tube (C) to Cross Tube (A) using Bolts (H) and fully tighten bolts.

Note: This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

