



Fitting Instructions

DETACHABLE TOWBAR SK12Q
For Skoda Octavia
2004-

MATERIALS

A	1	Cross Bar
ZQ	1	ZQ2038 Detachable Kit
D	2	Sidearms
E	8	M12 x 40 x 1.75 Bolts, 2 Nuts, Lock Washers and Flat Washers (30mm O.D)
H	1	Bumper insert kit
ZEP3	1	Electrical plate with Type Label
ZEQ2	1	Safety Chain Bracket

FITTING

1. Remove bumper, 6 Torq head screws in each wheel arch, 1 Torq head screw in each lower corner of bumper, 4 screws along lower edge of bumper and 1 screw under each light cluster, 2 bolts behind side trim. Remove crash beam and hand to end user for refitment when bar is removed.
2. Insert sidearms (D) into chassis rails and loosely attach using fixings (E) with flat washers.
3. Attach main bar (A) using remaining fixings (E). **(Fully Tighten all Bolts)**
4. Cut bumper as shown and refit bumper.
5. Fit Detachable Kit ZQ- Please refer to ZQ fitting instruction.

Note: This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M16 - 214 Nm

