



Fitting Instructions

TOWBAR **SZ7AR**
For **SUZUKI GRAND VITARA**
1998 -

MATERIALS

A	1	Cross Bar
D	1	Left hand Sidearm
E	1	Right hand Sidearm
F	4	M12 x 30mm x 1.25mm Bolts, Lock Washers and (25mm O.D.) Flat Washers
G	4	M12 x 35mm x 1.75mm Bolts, Nuts, Lock Washers and (25mm O.D.) Flat Washers
EP	1	Electrical Plate
R	1	ZR2M000 – Witter Detachable Unit

FITTING

1. Remove and discard towing eye, where fitted.
2. Loosely attach Mounting Cleats (D) and (E) to underside of vehicle frame using fine pitch Bolts (F) with Flat Washers.
3. Locate Cross Bar (A) to Mounting Cleats (D and E) using Bolts (G) with Flat Washers.
4. Loosely attach Detachable Unit (R) to Cross Bar (A) – please refer to ZR2 Detachable Towball System fitting instruction supplied – **Note:** Paragraph 1 of fitting instruction does not apply to this towbar.
5. Fully tighten all Bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.
Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

