



Fitting Instructions

TOWBAR SZ8R
For Suzuki Jimny 2000-

MATERIALS

A	1	Cross Bar
C	2	Angle Bracket
D	2	Bolt Strap
E	4	M12 x 1.75 x 30mm long Bolts, Nuts and Lock Washers
F	2	M12 x 1.75mm Nuts and Lock Washers
G	1	M10 x 1.5 x 30mm long Bolt, Nut, Dia20mm Flat Washer and Lock Washer
EP	1	Electrical Plate
R	1	ZR2L000 – Witter Detachable Unit to 94/20/EC – A50-1

FITTING

1. Remove bumper:
 - a. Remove two shoulder screws from bottom edge near each towing eye.
 - b. Remove two upper screws securing each mudguard to the bumper.
 - c. Remove three shoulder screws from the top bumper edge.
 - d. Locate the lighting wire entry into the vehicle bodywork (L.H. corner near end of chassis rail) pulling out rubber grommet to gain access to wiring sockets; disconnect sockets.
 - e. Remove rear light clusters (2 screws behind door, each side of vehicle) to gain access to the final bumper securing screws, (1 shoulder screw behind each light cluster).
2. Insert bolt straps (D) into forward most mounting hole by inserting from end of chassis rail.
3. Assemble angle brackets (C) to bolt (D) and loosely secure with fasteners (F).
4. Position Cross Bar (A), with R.H.S. located over top of exhaust tail pipe, loosely secure with fasteners (E) in 4 places and fasteners (G) in the centre of the three L.H.S. mounting holes.
5. Loosely attach Detachable Unit (R) to Cross Bar (A) –refer to ZR2 Detachable Towball System fitting instruction supplied – **Note:** Task 1 of “Fitting of Towball Receptor” does not apply to this towbar.
6. **Fully tighten all fasteners.**
7. Refit bumper.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

