



# Fitting Instructions

TOWBAR TA3  
For TATA SAFARI

## MATERIALS

A	1	Towbar with European facing to 94/20/EC A50-1
B	1	Spacer
C	2	M16 x 70mm fine pitch bolts and lock washers
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

## FITTING

1. Remove access cover from centre of bumper to reveal towbar mounting holes.
2. Attach Spacer and Towbar, Parts A and B to towbar mounting visible through bumper aperture, using bolts C.
3. **Fully tighten all bolts.**

**Note:** This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

