



Fitting Instructions

TOWBAR VW22B
For VW GOLF
FEBRUARY 1984- Spring 1992

MATERIALS

A	1	Towbar Mainframe with international facing to ISO 3853 (BS AU114)
C	2	Bumper support brackets
E	2	M8 X 20mm Bolts, Nuts and Lock Washers
F	4	Large Flat Washers (40mm O.D.)
CB	2	M16 x 50mm Coupling Bolts, Nuts, Lock Washers

FITTING

1. Remove bumper. Remove and discard mounting arms.
2. On vehicles with SMALL PLASTIC BUMPER attach bumper to the Towbar Mainframe (A) using existing bolts at (X). On vehicles with LARGE PLASTIC BUMPER cut out the aperture in the bumper, as shown. Insert faceplate of towbar mainframe (A) through the bumper aperture and attach bumper Support Brackets (C) to the towbar mainframe (A) using Bolts (E) and to the bumper using the existing bolts at (Y).
3. Tighten all bolts then offer up towbar and bumper assembly into vehicle chassis and attach using existing bolts and large Flat Washers (F).
4. Finally tighten all bolts.

Note: For 4WD Syncro models, Volkswagen specify higher trailer weight and nose loads. This bracket is only suitable for 2WD towing weights and nose loads.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

