



# Fitting Instructions

TOWBAR VW36A  
For VOLKSWAGEN GOLF ESTATE  
April 1994- Summer 1999

## MATERIALS

A	1	Towbar Mainframe with European facing to 94/20/EC – A50-1
E	4	M10 x 30mm x 1.5 Bolts, Lock Washers and Large Flat Washers (40mm dia.)
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers

## FITTING

1. Remove bumper (4 bolts behind covers on top, 3 bolts underneath, 2 self-tapping bolts at bumper tips). Remove and discard crush cones. Cut aperture in bumper as shown below. Remove soundproofing from inside chassis.
2. Locate existing holes on inner face of chassis, and remove tape-covering holes. Remove excess underseal to ensure correct seating. Offer towbar into vehicle chassis and attach using Bolts (E) into captive nuts on sidearms. Finally, **Tighten all Bolts.**

**Note:** Prepare for wiring before replacing bumper.

Volkswagen insists that extra cooling is required for the engine when towing. Please consult your VW / Audi dealer for parts required.

**Note:** This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed.**

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

