



Fitting Instructions

TOWBAR VW52Q
For Volkswagen Touran

MATERIALS

A	1	Cross Bar
ZQ	1	Detachable Neck (ZQ3006)
D	4	M12 x 40 x 1.75 Bolts, Lock Washers and Flat Washers (30mm O.D)
E	1	M10 x 25 x 1.5 Bolt, Nut, Lock Washer and 2 Flat Washers (25mm O.D)
F	1	Electrical Plate (ZEP1)
G	1	Electrical Plate Angle (ZEQ1)

FITTING

1. Remove bumper, 6 Torq head screws in each wheel arch, 1 Torq head screw in each lower corner of bumper, 4 screws along lower edge of bumper and 2 screws under each light cluster. (**Note:** Light cluster is held on by 2 screws under plastic trim on side of lights, and slides off sideways)
2. Remove crash beam and hand to end user for refitment when bar is removed.
3. Insert crossbar (A) into chassis rails and loosely attach using fixings (D).
4. Attach Detachable Neck (ZQ) and Electrical Plate Angle (G) as per separate fitting instruction. (**Tighten all Bolts**)
5. Cut bumper as shown and refit. (**Note:** It is advisable to protect outer face of bumper whilst refitting).

Note:

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

