



Fitting Instructions

TOWBAR CL75
For MITSUBISHI CANTER
1998-

MATERIALS

A	1	Tubular Mainframe
D	6	M12x45 Bolts and Nyloc Nuts
E1	2	Spreader Plate (2 holes)
E2	2	Spreader Plate
B	1	10mm Coupling Packer
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers

FITTING

1. Lower spare (where fitted) and enlarge holes in chassis using a 12.5mm dia. drill for Bolts (D), attach Crossbar (A) with Spreader Plates (E1) and (E2) fitted inside chassis. Fully Tighten bolts and raise spare wheel.

NOTE: On vehicles where the chassis has been shortened (i.e. Tipper Conversions) holes at (D) may not be present and will require drilling using the Crossbar (A) as a guide (ensure rearmost hole at (D) on chassis is at least 15mm from end of chassis.)

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm , M14 - 150 Nm, M16 - 214 Nm

