



Fitting Instructions

TOWBAR HN49
For HONDA STREAM
June 2001-

MATERIALS

A	1	Towbar Main Frame with international facing to 94/20/EC A50-1
D	1	Side Arm (Left hand)
E	1	Side Arm (Right hand)
F	4	M12 x 30 x 1.75mm Bolts, Nuts and Lockwashers
G	6	M12 x 35 x 1.75mm Bolts, Lockwashers and Large Flat Washers (50mm O.D.)
CB	2	M16 x 50 x 2.00mm Bolts, Nuts and Lockwashers.

FITTING

1. Remove the bumper (2 tip screws, 4 mudguard screws and 2 plastic plugs on the lower edge). Remove the steel beam (4 bolts). Cut the bumper as shown.
2. Insert Side Arms (D and E) into the chassis and loosely attach using Bolts (G).
3. Loosely attach Towbar Main Frame (A) to Side Arms (D and E) using Bolts (F). Tighten all Bolts and refit the bumper.

Note: This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

