



Fitting Instructions

TOWBAR HY11
For HYUNDAI LANTRA
4 DOOR SALOON
1991-1995

MATERIALS

A	1	Main Cross Member
A1	1	Forward Cross Bar
C	1	Centre Tube with international facing to ISO 3853 (BS AU114)
D	4	M12 x 30 x 1.75mm Bolts, Lock Washers and Large Flat Washers (40mm O.D.)
E	2	M12 x 30mm Bolts, Nuts and Lock Washers
F	2	M10 x 25mm Bolts, Nuts and Lock Washers
G	3	M10 x 25mm Bolts, Nuts, Lock Washers and large Flat Washers (40mm O.D.)
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers
	3	M10 black Plastic Bolt Caps for (G)

FITTING

1. Remove bumper and lashing down eye on left hand side of vehicle (2 bolts horizontally through chassis, 2 tip bolts and 1 plastic plug on each side of the vehicle), discarding the original 4 mounting bolts. Remove and discard the bumper arms from the bumper moulding, retaining the 8 x M8 nuts. Cut off towing eye at the centre of the spare wheel pan.
2. Attach Main Cross Member (A) to the bumper studs (X), using the original nuts, slide the assembly into the vehicle chassis and loosely attach to vehicle using Bolts (D).
3. Loosely attach Centre Tube (C) to Cross Member (A) using Bolts (E) and to Forward Cross Bar (A1) using Bolt (F).
4. Centralise Forward Cross Bar (A1) on spare wheel pan and, holding forward against the transverse reinforcement pressing, drill up through the vehicle for Bolts (G) using the holes in the towbar as a guide. Attach Bolts (G) with large flat washers inside the vehicle. Finally tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

